Sonos Play



Overview

Powerful, portable, and ready for anything. Play delivers big Sonos sound and all-day battery life wherever you go.

- **Big sound. Just the right size.** The room-by-room sound and deep bass in a surprisingly compact design. Play delivers powerful, balanced audio that fills the room with your favorite music.
- **Battery life that goes and goes.** Listen all day with up to 10 hours of playback, and recharge easily with the included charging base. Optimized power management extends every charge, and allows it to last for a full year of daily use before battery replacement.
- **Ready for whatever your day holds.** Don't spend all your time in the outlets. Play is IP67 rated for waterproof and dustproof protection, and the durable design packs handles, straps and bumpers.
- **Stream your music, your way.** Play is the ideal way to add Sonos sound to your home and wherever you go. Play connects wirelessly to Sonos Controllers and Bluetooth® devices from trusted sources. Play is also compatible with the Trueplay app, your ears, and Sonos.
- **Power more than your music.** You control the volume. Play doubles as a power bank so you can keep your phone charged and your playing wherever the data you.

Controls and lights



Volume control

- Volume up button (+)
- Volume down button (-)

Note: When music is playing, press and hold + or - to quickly change the volume.



Play/Pause

- Press once to play or pause audio.
- Press and hold to sign in with the Sonos app (when playing in another room or signed out).



Next

- Double press (skip)press to skip to the next track.

Note: You can't skip forward on a stand when listening to a radio station.



Previous

- Triple press (skip)press to go to the previous track.

Note: You can't skip backward on a stand when listening to a radio station.



Voice services on/off

Press the voice services button to turn voice control on or off. You can set up a voice service in the Sonos app.

- When the light is on, voice control is enabled.
- When the light is off, voice control is disabled.

Note: Make sure the universal microphone switch on the back is turned on.



Status light

Displays the product's connection to Wi-Fi or Bluetooth, indicates when the battery is charged, and signals errors. **Learn more**



Battery light

Indicates the battery status:

- Blinking orange: low battery
- Solid orange indicates Play has started charging. The light will turn off in 15 seconds. Wait for it, unless the battery is very low.

Note: Avoid battery level of the Sonos App.

Connector panel



1	**Strap**	Attach for heavy lifting and carrying so you can take Play Five wherever you go. To remove the strap, use a 3.5mm hex key. The internal thread noted with M4.
2	**Bluetooth button**	Press to connect to a mobile device via Bluetooth. Play will connect to the last device it connected to. Press again to disconnect the current device. Press and hold to pair a new device.
3	**Universal microphone switch**	Turn all the microphones on or off. Press once to turn on voice control in the Sonos app. When the switch is off (down), the microphones are disabled so microphone-based features like Trueplay and voice control are unavailable. Sonos recommends to use, microphone related features like audio. Trueplay and voice control, when it is not in use, to protect your privacy. Use the universal microphone switch to turn off the microphones.
4	**Power button**	**Press to power on.** The status light turns on and you hear a Sonos chime. **Press to exit to sleep.** The status light turns off and you'll hear a short tone. **Press and hold about 10 seconds to power off.** The status light turns off. **Note:** The turn off and wake up after 20 minutes when it is disconnected from power.
5	**USB-C port**	• **Power.** Use a component USB PC power supply (1.5A/5V) to charge Play. Play will not charge from a computer. • **Ethernet.** Use the Sonos Combo Adapter and an Ethernet cable to connect Play directly to your router. Play will connect to your network if your Wi-Fi is unstable. • **Line-in.** Use the Sonos Combo Line-in Adapter or Combo Adapter to connect your turntable, CD player, or other audio source to Play. **Power tank.** Play doubles as a power bank so you can keep your phone charged.
6	**Charging dock**	Set Play on the charging base and it stays active for an hour even after playback stops. **Note:** Play is designed to work with POWERSYNC PS-2410UR-01 compliant adapters, but 6W2 (5V/2A) is recommended. Check the 6 rating on your power that battery use.

Charging



Charging base

Set Play on the charging base for easy recharging. The battery light will turn on when Play is charging and turn off when it's fully charged. Use the charging contacts (on the front).

The charging base is for indoor use only. Do not use outdoors.

Note: Check battery level in the Sonos app.



USB-C port

Plug a standard wall USB-C power adapter (1.5A/5V) or USB computer USB power supply (1.5A/5V) to charge Play.

Play will charge when powered either device via USB-C connection.

Battery Saver

Battery Saver helps you get more out of Play's battery. When enabled, your Play will power off automatically after 5 minutes of inactivity. Then, the next time you press Play, it will start playing.

Go to **Settings** > **Battery Saver** to turn on Battery Saver.

Note: Play won't appear in the Sonos app until it's powered back on.

Bluetooth pairing

1. Turn Bluetooth on in your device settings.
2. Press and hold the Bluetooth button at the speaker until you hear a tone, then release. The status light blinks blue when the speaker is ready to pair.
3. Select your Play from the list of available Bluetooth devices in your device settings. Your mobile device will automatically connect and then you can play the Bluetooth audio.

Select a location

Play can be placed in any room or location in your home. Play's Trueplay tuning feature will automatically optimize the sound for its location.

Trueplay works on iOS mobile devices running iOS 9 or later. Tuning Sonos, you'll move around the room holding your mobile device.

1. Open the Sonos app, and go to **Settings** ⓘ.
2. Choose one of the products you want to tune in the stereo pair.
3. Select **Set Up Stereo Pair** to get started.

Learn more

Microphone on/off

The microphones in Play are used for voice control and other features found in the **Sonos app**. Mic on/off

Turning the microphones off disables Trueplay and other features that require microphones. Play will still function as a wireless speaker.

The universal microphone switch on the back allows you to turn on or off all microphones in the speaker and is found on the back of the speaker next to the Ethernet port. When disabled, the microphones are physically disconnected from the electronics.

When the voice services light is on

- Voice control is enabled. Be ready to listen.
- The universal microphone switch is on.

When the voice services light is off

- Voice control is disabled. Play will not listen.
- The universal microphone switch is set to off.

Voice services

Use your Sonos to control your Sonos system with any voice-enabled Sonos product. Ease and control content, from the comfort of your armchair.

- **Sonos Voice Control** lets you control your Sonos system with your voice. Play is ready to go with Sonos Voice Control. Learn more about Sonos Voice Control and which products support it.
- **Amazon Alexa** gives you hands-free Sonos play and Play with the Sonos Skill available. Track music, radio, podcasts, and more. Learn more about Amazon Alexa.
- **Siri** is built into Apple iPhone, iPad, and Mac and lets you control Play using your voice. Ask Siri to play music, pause, or skip tracks. Learn more about Apple Siri.

Note: Sonos doesn't support all voice services in every country. Check the features will be available as soon as Sonos and a voice service launch together in your region.

Trueplay™

Every room is different. Trueplay tuning measures how sound reflects off walls, furnishings, and other surfaces in your room, and then fine-tunes the audio to sound its best in your space. Trueplay works on iOS mobile devices running iOS 9 or later. Tuning Sonos, you'll move around the room, holding your mobile device.

1. Open the Sonos app, and go to **Settings** ⓘ.
2. Choose one of the products you want to tune in the stereo pair.
3. Select **Set Up Stereo Pair** to get started.

Learn more

Auto Trueplay

Portable Sonos products like Sonos Roam and Move can tune themselves automatically. Auto Trueplay uses your speaker's microphone to detect the environment and make sonically-exciting adjustments so you get great sound wherever you take it. Auto Trueplay is on by default.

1. Select **Settings** ⓘ.
2. Choose the product you want to tune.
3. Select **Trueplay**, and turn on **Auto Trueplay**.

Set up stereo pair

Use the Sonos app to set up Play as a pair for even better, stereo experience. One speaker serves as the left channel and the partner as the right channel.

Note: The Sonos speakers in a stereo pair must be the same type.

1. Open the Sonos app, and go to **Settings** ⓘ. Select the speaker you'd like to be the left channel speaker, then select **Create Stereo Pair**.
2. Open the Sonos app, and go to **Settings** ⓘ.
3. Choose one of the speakers you want to use in the stereo pair.
4. Select **Set Up Stereo Pair** to get started.

Learn more

Product settings

You can customize Sonos products for your surroundings.

1. Go to **Settings** ⓘ.
2. Select a product.

Room Name	If you have your speakers in a new room, you can change its name in **Settings**.
Turn off EQ (not available for Sonos Era 100, Era 300, or portable products)	You can turn off your speaker's EQ® when it's connected to your network with an Ethernet cable. Turning off EQ can be helpful when you're using your speaker with a home theater system. For products like Beam and Port, turning off EQ can reduce the volume of dialogue in TV shows and movies. Learn more about EQ and Night Sound.
EQ	**Note:** EQ is not available on Sonos Amp and Amp S2. Learn more about using **Sonos Combo Adapter** using the Ethernet port.
Trueplay	Trueplay adapts the sound to your surroundings and content. Portable products can use microphones and motion sensors. **Learn more**
Volume Limit	You can set a maximum volume for each room. **Learn more**
Status Light	Disables the speaker's connection to Wi-Fi, indicates when the volume is muted, and signals errors. **Learn more** **Note:** If the light is blinking, you can turn it off in **Settings**.
Touch Controls	You can disable the touch control on your speaker. The Sonos app will not be able to present a full control panel for your speaker if you disable touch controls.
Battery Save (available products only)	In your battery life, you can set your portable speaker to power off automatically instead of going to sleep. It won't appear in the Sonos app until it's powered back on.
Line-in (Sonos products with line-in capability)	When a product, turntable, stereo, or other audio device is connected to a product's line-in port, you can change the settings. • **Source name.** Choose a name for the line-in device. • **Auto-Play.** Start the line-in source even if you find the default volume setting to be quiet or distorted. • **Audio Delay.** Add a delay between the line-in source and Sonos to reduce audio lag. Use this setting if you're watching video and playing the audio in a Sonos product. • **Autoplay.** Chooses to start if you want line-in audio to start playing automatically when Sonos detects a signal on the line-in port.

Grouping out of the home

You can group your Play with other Sonos products so they can play music even together, each content on one speaker, then press and hold the play/pause button on another to play them together.

You can press and hold the play/pause button on one speaker to add or remove them from a group.

Drying your Play

Play has an IP67 rating, which means water-proof and can be submerged in water up to 1 m (1 meter) for several minutes.

- Make sure the speaker is submerged in up to 1 m (1 meter) of water for up to 1 hour. Learn how to the speaker and the water. Wait up to 6 hours for it to dry.
- Position the speaker vertically until it drains. Then place it face down (logo side down) on a dry towel for a few minutes.
- Dry it with a towel. Wipe it dry.
- Let it air dry for at least 24 hours before using it with the Sonos app.

Important: Don't plug any device into the speaker's Ethernet port until it's completely dry.

Specifications

FEATURE	DESCRIPTION
Audio	
Amplifiers	Three Class-D digital amplifiers
Tweeters	Two angled tweeters create a crisp and accurate high-frequency response and stereo separation
Woofers	One woofer(s) ensures the faithful playback of mid-range and frequencies and deep bass.
Microphones	• Far-field beamforming array • Anti-reflective, noise-rejecting voice control, can be turned off using the universal mute button switch on the back of the speaker.
Voice	• Amazon Alexa built-in • When the voice services light is off, voice assistants are not listening but other microphone features, like Trueplay, may be in use. Turn off the microphones using the universal mute button on the back of the speaker. **Note:** The universal microphone switch must be turned on.
Auto Trueplay™	This software continually optimizes the speaker's sound for its environment and content. Learn more Enable in the Sonos app. **Note:** The universal microphone switch must be turned on.
Adjustable EQ	Use the Sonos app to adjust: • Bass • Treble • Loudness

Power & Connectivity

Charging base	USB-C PD power with 15W (5V/3A) to 45W (15V/3A). Output: 5V 9V 15V 20V
Battery (rechargeable)	Built-in, lithium-ion **Capacity.** 9955 mAh **Replacement.** Visit our website for more information. **Battery life.** Battery life varies depending on playback volume.To determine the battery life of your product, see the Sonos app.
Wi-Fi	Connects to 5 GHz* network with any 802.11 a/b/g/n/ac (2.4 GHz or 5 GHz) broadband wireless router *Bluetooth 5.3 supports audio streaming from any Bluetooth-enabled device
Bluetooth	
USB-C	Connect an audio source using an auxiliary cable and the Sonos Line-In Adapter. Connect your router with an Ethernet cable and the Sonos Combo Adapter. Connect your Ethernet cable to the Combo Adapter. Connect a component to the charger must be between 1A-3.78Ah required for Sonos Play. Use a component with less than 1A or more than the required capacity.
Ethernet	
Charging	
CPU	QUAD CORE ALLWINNER A33
Memory	1 GB DDR3 8 GB NV

Details & Dimensions

Dimensions (H x W x D)	7.83 x 6.30 x 2.85 in (199 x 160 x 72.5 mm)
Weight	2.99 lb (1.3 kg) (includes battery)
Operating temperature	32° to 104° F (0° to 40° C)
Storage temperature	-13° to 158° F (-25° to 70° C)
Humidity resistant	Play meets IP67 water and dust resistance levels. **Note:** The charging base is for indoor use only.
Colors	Black Matte white
What's in the box?	Play, charging base with 6 ft (2 m) USB-C to C cable, and Quickstart guide.

Important safety information

Caution: Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.

- Read these instructions.
- Keep these instructions.
- Heed all warnings.
- Follow all instructions.
- Do not use this unit near water.
- Clean only with a dry soft cloth. Household cleaners or solvents can damage the finish on your Sonos product.

Sonos products with rubber rings on the bottom, such as Move, Move 2, One, and One SL, don't ship they leave rubber rings can leave surface marks on tables and wood surfaces. Put a coaster or towel between your Sonos product and the surface.

- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus that produce heat.
- Do not expose to rain/snow, ordinary use or moisture installed or operated near water or any liquid.
- Protect the power cable from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to Sonos qualified service personnel. Servicing is required when the apparatus has been damaged in any way.
- Sonos Play meets IP67.