Wireless Doorbell Button





OVERVIEW

The Axxess Wireless Doorbell Button is beautifully designed to welcome guests at your door. A press of the button wirelessly activates our chime relay or other configured devices.

Installation is simple. With a long lasting lithium battery there is no wiring necessary and its surface mount design means you have a choice between using two screws or the peel and stick adhesive strips.

Since the Axxess Doorbell Button communicates with the controller, doorbell rings can be turned off for pre- programmed events such as "baby asleep." Fully compatible with Control4.

Two external contacts enable detection of whether the door is closed and whether the deadbolt is engaged







Wireless Doorbell Button

USES

- Chime activation
- Multi-purpose button

WIRELESS

ZigBee PRO (802.15.4) Control4 driver downloadable

COMPLIANCE/APPROVALS

FCC Part 15 | CE

TEMPERATURE SENSOR

Accurate to +/- 1°C Operating range of -40°C to 70°C

BUTTON FUNCTION

Button press sends wireless ZigBee message to controller or directly to Doorbell Relay

POWER SPECS

3.6 V AAA cell (ER14505), -55C to 85C range in temperature Low battery notification

EXTERNAL CONTACTS

Magnetic or wire leads optional

COLOR

Black | White

DB-C4ZB-11

DIMENSIONS

W 1.1875" x H 2.75" x D 0.5" W 3.02cm x H 6.99cm x D 1.27cm

MOUNTING

Double sided adhesive or 2 screws

DRIVERS

Download from axxind.com/dealers/drivers

HOW TO ORDER

axxind.com/dealers

WHAT'S IN THE BOX



