



Positioning & Installation Guidance

Deploy Josh Nano on a wall or ceiling to fit any room's design aesthetic and functional needs.

- Carefully consider a room's acoustics to ensure the audio path from someone speaking to Josh Nano is clear, uninterrupted, and is not distorted by an echo.
- Locate Josh Nano 3 - 4 feet from speakers or other sources of noise so that the microphones are not exposed to background noise.
- Mount Josh Nano at a height of approximately 56 inches above the floor for an optimal sound path.
 - It is recommended to locate Josh Nano near entrance ways to rooms, similar to keypads or switches, so that the microphone is readily available as someone walks into its area.
- Josh Nano is powered by ethernet, which requires category cable to be run to each of its locations.
- Each Josh Nano location must be a surface with at least 1/2 inch of material depth in order to accommodate its internal mounting bracket and body.
- A completed deployment will expose Josh Nano's 1.6 inch diameter cap 3mm above its mounted surface.
- Paintable circular or square covers can be placed over Josh Nano to make it truly invisible.
- Please note that the paintable covers impede clients from:
 - Tapping Josh Nano's capacitive touch surface
 - Physically disabling the microphones via Josh Nano's privacy switch
 - Seeing Josh Nano's LED light ring for visual feedback



Cutaway illustration showing the final assembly of all Josh Nano components in-wall.